



USB



WIFI  
> LOCK  
> NORMAL  
> CONFIG



MODE  
Ethernet  
10/100



STATUS

LINK/ACT

Z-5R

GROUND	○	⊕
BUTTON	○	⊕
+12V	○	⊕
LOCK	○	⊕
EX.OPEN	○	⊕
GROUND	○	⊕
DOOR	○	⊕
ALARM	○	⊕
ALARM	○	⊕

OPER  
CONN

BEEP	○	⊕
RED	○	⊕
GREEN	○	⊕
DATA 1	○	⊕
GROUND	○	⊕
DATA 0	○	⊕
+12 V	○	⊕